

EGGSTERMINATOR

your scratch-free cleaning superhero

Eggsterminator is unique – he gets firm when you put him in cold water and soft when you put him in warm water!

Use him FIRM (cold water) for scrubbing and heavy duty cleaning or SOFT (warm water) for lighter jobs.


Having Eggsterminator around is like having two amazing cleaning tools in one!



No amount of ground-in dirt is a match for Eggsterminator!



He'll remove baked on grease and grime with ease!



Eggsterminator can even peel vegetables!

POW!



His smiley face is functional too!

ZAP!



Eggsterminator fits into the tightest spaces and you always have control!



Just pop him in the dishwasher to sanitise - he'll be as good as new!



Frequently Asked Questions

Wait, I can use Eggsterminator both FIRM and SOFT?

Yes! The unique material that Eggsterminator is made from changes texture depending on the water temperature.

Put Eggsterminator in cold water and he becomes FIRM – great for scouring and more robust scrubbing.

But, put Eggsterminator in warm water and he becomes SOFT – great for dishwashing and lighter cleaning duties.

How do I keep my Eggsterminator fresh and clean?

Easy – just pop him in the dishwasher! That will make sure he's always clean, fresh, and ready to get scrubbing!"

My Eggsterminator doesn't get that firm under cold water?

Is your water really cold? Sometimes, especially in the summer, the cold water from our taps isn't actually that cold.

Try putting Eggsterminator in a bowl of cold water with some ice cubes in it.

Or – better still – keep an Eggsterminator in the fridge or freezer, so you have always got a firm one at hand ready to go.

Do I need to use a detergent with Eggsterminator?

No, in most cases, water alone is enough. However, you can use a little detergent if you wish for extra tough messes. For an eco-friendly option, try using baking soda!

How should I best dry my Eggsterminator?

Eggsterminator dries quickest when sat on edge – he'll usually be dry in just an hour or two.

How about pushing his smiley face over your tap to let Eggsterminator dry super-quick and so he is always smiling at you in the kitchen!

How long can I expect my Eggsterminator to last?

This is a tricky one because everyone uses their Eggsterminator in different ways. Generally, you can expect to get up to about 2 months of use from each Eggsterminator.

For hard use, your Eggsterminator may naturally start to crumble or tear within 2 months of use. This is perfectly normal, so don't throw him out. Keep him handy for those outside jobs, an older Eggsterminator is great for cleaning garden furniture and car wheels.

Will Eggsterminator Scratch Surfaces

The unique material from which the Eggsterminator is made helps to prevent scratches.

However, it's impossible to test every single surface, so we always recommended doing a patch test in an inconspicuous area if you are unsure.

Remember, some detergents are abrasive themselves and can scratch surfaces.

Please note: The material that the eggsterminator is made from is very unique. Therefore, you may notice small differences in the size and thickness of each eggsterminator. Please be assured that this is a perfectly normal part of the manufacturing process and will not affect your enjoyment of this product in any way.

Ecoegg Ltd

Ecoegg House, Unit 21, Integra, Bircholt Road,
Maidstone, Kent, ME15 9GQ, UK

Tel: 00 44 (0) 1622 535 200 Email: hello@ecoegg.com

www.eggsterminator.com

Made in P.R.C.